



Stressless® Metro Family



Star Base



Office Base



Stressless® Metro Family - Measurements (inches)

Item no.	Size	Base	Option	Width	Height	Depth	Seat Height	Seat Depth
1291310	Metro	Star	Chair Low Back Standard Base	31.5	34.3	27.6	16.9	18.8
1291311	Metro	Star	Chair Low Back High Base	31.5	35.8	27.6	18.5	18.8
1292310	Metro	Star	Chair High Back Standard Base	31.5	44.1	28.0	16.9	18.6
1292311	Metro	Star	Chair High Back High Base	31.5	45.7	28.0	18.5	18.6
1291097	Metro	Star	Office Low Back	31.5	38.2 - 40.9	27.2	16.9	18.0
1292097	Metro	Star	Office High Back	31.5	48 - 50.8	27.6	16.9	18.4
1292313	Metro	Star	Ottoman Standard Base	21.3	16.5	16.1		
1292314	Metro	Star	Ottoman High Base	21.3	18.1	16.1		

The headrest adjusts automatically, so you can read and watch TV, even in a reclining position.

The Plus™ system adjusts the lower back support simultaneously with the headrest. Upright or reclined, you're always perfectly supported.

Lower the headrest to the sleep position with one simple movement.

Adjust the Stressless® Glide wheels to the setting of your desire. You can automatically shift to any seating position simply by using your body weight.

Comfort Zones™ give you a better seating comfort, as the indentations let you sink deeper into the seat and back of the recliner.

Your Stressless base rotates a full 360°. Choose between different base options such as the Star Base and the Office Base.

